

Code list for direct set of TVs, DVD's and amplifiers using HD PVR remote

TV's

1652 Acer	T1339	T1509	T1644						
1849 Aim	T0805	T0698	T0753	T0634	T0037	T0208	T0455	T0606	T0451
	T0374	T0412	T0706	T0556	T0072	T0499			
0406 Aiwa	T0701	T1916	T0705	T1908	T1505	T1910	T1904		
0098 Akai	T0602	T0706	T0037	T0371	T0009	T0361	T0208	T0035	T0556
	T0753	T0714	T1537	T0433	T1037	T0480	T0745	T0672	T0412
	T0812	T0377	T0264	T0191	T0715	T0218	T0581	T0329	T0803
	T0178	T0606	T0631	T1259	T0473	T1248	T0702	T0548	T0294
	T0696	T0072	T0163	T0806	T0729	T0448	T0516	T0826	T0488
	T0217	T0216	T1908	T0648	T1935				
2663 Akira	T0418	T0037	T0753	T0858					
2688 Bauer	T0698	T0805	T0009	T0264	T0706				
0133 Blaupunkt	T0036	T0200	T0195	T0554	T0191	T0535	T0213	T0327	T0448
	T0455	T0170							
0092 Daewoo	T0499	T0634	T0706	T0374	T0037	T0661	T0698	T0451	T0556
	T1909	T1908	T1902	T0624	T0009	T1137	T0880	T0876	T0841
	T0178	T1218	T0865	T0672	T0218	T0216	T0032	T0217	T0170
	T0108	T0150	T0714						
0247 Diamond	T0825	T0860	T0896	T0672	T1681	T0706	T0264	T0820	T0698
	T0009	T0371	T0216	T0696	T0804				
0284 Etron	T0820	T0001	T0009	T0037	T0556	T0163			
0313 Fujitsu	T0853	T0683	T0809	T0186	T0037	T0072	T0009	T0556	T0361
	T0102	T0163	T0217	T0352					
1673 Fujitsu Siemens		T1666	T1298	T1248	T1163	T0808	T1373	T1259	T0809
2749 Futronic	T0860	T0795	T0264	T0698					
0056 Goldstar	T0178	T0037	T0001	T0556	T0377	T0370	T0714	T0715	T0217
	T0247	T0431							
		T0606	T0009	T0032	T0150	T0216	T0163	T0361	T0109
	T1934	T0455		T1934	T0455				T0044
0345 Grundig	T0195	T1223	T0070	T1371	T0535	T0191	T0037	T0554	T0487
	T0443	T0009	T0178	T0706	T0672	T1935	T0556	T0036	T0370
	T0418	T1908	T1916	T0343	T0508	T0587	T1876		
2159 HiSense	T0706	T0208	T0780	T0860	T0037	T0264	T0698	T0891	T0009
	T0848	T1363	T1069	T0556	T0821	T1071	T1073	T0508	T1082
	T0696	T1070	T0753	T1075	T0811	T1026	T1314		
0145 Hitachi	T0225	T0499	T0349	T0578	T1576	T0634	T1037	T0719	T0797
	T0481	T0473	T1481	T1484	T0492	T0744	T0548	T0480	T0044
	T0361	T0037	T0109	T0036	T1137	T0343	T0737	T1904	T0196
	T0105	T0356	T0217	T0108	T0178	T0516	T0072	T0163	T0009
	T0186	T0884	T0032	T0179	T0512	T0213	T0508	T0877	T0556

0093 Sharp	T0093	T1193	T0818	T0036	T1393	T1586	T0491	T1163	T0186	
T0009	T0032		T0294	T0653	T0650	T0516	T0200	T0760	T0412	
2909 Show	T0698	T0009	T0264	T0037	T0706	T0418	T0072			
0864 Silver	T0455	T0037	T0361	T0036	T0556	T0179	T0715	T0163		
2911 Sinotec	T0773	T2012	T1708	T0418	T1777	T0606	T0698			
0000 Sony	T1505	T1651	T0011	T0036	T1010	T1751	T0353	T1962	T0650	
T0102	T0037		T0556	T0093	T0170	T0074				
2544 Supersonic	T0208	T0009	T0037	T0698	T0455	T0805	T0556	T0264		
1813 SVA	T0698	T0208	T0455	T0805	T0264	T0706	T0037	T0865	T0587	
T0899	T0768		T0872							
0934 Technol Ace	T0698	T0264	T0634	T0374	T0179	T0216				
1970 Tedalex	T0606	T0037	T0698	T0806	T0009	T0264	T0418	T0706	T1681	
T0556	T1709		T0217	T1537	T0208	T0891	T0431	T0587	T1531	
1899 Tek	T0795	T0698	T0820	T0037	T0811	T0892	T0009			
0757 Telefunken	T0343	T0698	T0074	T0820	T0896	T0821	T0560	T0706	T0037	
T0712	T0753		T0556	T1626	T0625	T0109	T1681	T0287	T0819	
T0335	T1703	T1706	T1504		T1536	T1243	T0213	T0101	T0490	
T0891	T0498	T0714	T0754	T0471	T0780		T0196	T0702	T0587	
T1556	T0262	T0073	T0486	T0346						
3474 Topshow	T0698	T0773	T0418	T0009	T0264	T0706				
0156 Toshiba	T0035	T0508	T1508	T0718	T0553	T0698	T0618	T1556	T0036	T0736
T0009			T0037	T0714	T1916	T0060	T0650	T0264	T1945	T1163
T1935	T1704	T0070			T0093	T0102	T0217	T0412	T0109	T0490
T0195	T1908	T0821	T0191	T0644						
1535 Wharfedale	T0860	T0896	T0706	T1613	T1681	T0698	T1556	T1707	T0037	T0519
T0861			T1988	T0556	T0891					

Audio / Amplifiers

0406	Aiwa	R0121	R1405	R1347	R1158	R1258	R1822	R1722		
0098	Akai	R0115	R0440	R0609	R1390	R1436	R0346	R1220		
0246	Denon	R1360	R0004	A0272	R0771					
2609	Digitech	R1772	R2099							
2737	Enzer	A1129	A1381	R1772						
0356	Harman/Kardon	R1304	R1310	R0891	A0892	R1189	R1089	R1289	R0208	
0053	JVC	R0074	R0464	R1495	R1374	R1676				
0417	Kenwood	R1027	R1313	R0186	R1281	R0262				
0511	LG	R1293	R0281	R1524	R1869					
0128	Marantz	R1189	R1289	R1089	A0892	R0891	R0642	A0641	A0829	R1474
0513	NAD	R0320	R0609							
0102	Onkyo	R1320	R0135							
0051	Panasonic	R1763	R1518	R1309	R1779	R1765	R0367	R1308	R0039	R1316
0081	Philips	R1189	R1089	R1289	R0642	R1831	R1673	A0641	R1266	R1654
	R0891	R0346								
0166	Pioneer	R1023	R1459	R0080	R0289	R1623	A0300	R1284	R0244	R1384
	R1084	R1123		A0823	R1122	R1184	R1189	R0186	R1089	R1289
0630	Rotel	R0793	A0726							
0060	Samsung	R1295	R0286	R1199	R1424	R1581	R1281	R1868		
0067	Sansui	R0609	R1772	R1329	A1330	R1938	R0346	R1625	R1784	R1750
	R0593	R1324		R0286	R1961	R1089	R1571			
0159	Sanyo	R1801	R0360	R0801	R0744					
0000	Sony	R1158	R1758	R1858	A0689	R1822	R1454	R1658	R1258	R0415
	R1112	R1558		R1441	R1347	R1722	R1759	R1442	R1882	R2172
0041	Teac	R1279	R1199	R1390	R0463	R0609	R1479	R0797	A0421	R1281
	A1274	R1782		R1226	R0593	R0744	R1425	R1125	R1219	
0250	Technics	R1763	R1518	R1308	R1779	R1309	R0208	R1765	R0039	R1316
0757	Telefunken	R1390	R1772	R1571	R1389	R0824	A1478	R1128	A1330	R1780
1535	Wharfedale	R1772	R1390	R0440	R0609					
0019	Yamaha	R0176	R1331	R1276	R0712	A0354	A0848	R0186	R1815	R1949

DVD's

1849 Aim	Y1165	Y1177	Y0790	Y0672	Y0699					
0098 Akai Y0884	Y1115	Y1587	Y0716 Y0713	Y0790 Y0852	Y0779 Y0705	Y0788 Y1233	Y0898	Y0766	Y0690	
0092 Daewoo	Y0770	Y1918	Y1483	Y0833	Y0872	Y0705	Y0714			
0246 Denon	Y1634	Y0634	Y0490							
0247 Diamond	Y0768	Y1152	Y0770	Y0790	Y1115	Y2021	Y0651	Y0751	Y0723	
2737 Enzer	Y1099	Y1228	Y1517	Y0766	Y0770	Y0665	Y1005			
2749 Futronic	Y0893	Y1005								
1206 Hyundai	Y0850	Y0783	Y0766	Y1228	Y2021	Y0788	Y1152	Y0768	Y1061	
0053 JVC	Y0623	Y1901	Y1164	Y0539	Y1860	Y1275	Y0503	Y0867		
0417 Kenwood	Y0534	Y0490								
0511 LG	Y0741	Y1906	Y0591	Y0869						
0443 Logik	Y1832	Y0713	Y0884							
0051 Panasonic	Y0490	Y1908	Y1834	Y1905						
0081 Philips	Y0539	Y0646	Y1340	Y1846	Y2056	Y2084	Y0675	Y0503	Y1158	
0166 Pioneer	Y0571	Y0631	Y1965	Y0525	Y1571					
0060 Samsung	Y0573	Y1932	Y0744	Y0298	Y1075	Y1928	Y0820	Y0490		
0067 Sansui Y2021 Y0723	Y1832 Y1553	Y1152 Y1933	Y0770 Y1684	Y1230 Y0751	Y1115 Y0695 Y1894	Y1884 Y1829 Y0826	Y0768 Y1228 Y2005	Y1051 Y0716 Y1316	Y1341 Y2058	
0159 Sanyo	Y0670	Y1919	Y0695	Y0790	Y0713	Y1228				
0688 Singer	Y0751	Y1152	Y0716	Y0690	Y0723	Y0768				
2911 Sinotec	Y0770	Y1115								
0000 Sony Y1261	Y0533	Y1070	Y1981	Y1633	Y2020	Y1516	Y0864	Y2043	Y1536	
0041 Teac Y0741 Y0758	Y1006 Y0833	Y1224 Y1227	Y1377 Y0571	Y0717 Y2059	Y1930 Y2063 Y1165	Y0516 Y0692 Y0675	Y1935 Y1152 Y1228	Y0790 Y0768	Y0759 Y0591	
1970 Tedalex	Y0768	Y1004	Y1152	Y0770	Y1228	Y0690	Y2021	Y1061		
0757 Telefunken	Y0789	Y0788 Y1923	Y0770 Y1083	Y0790 Y0613	Y1832 Y0594	Y1483 Y2066	Y0758 Y1345	Y1115 Y1555	Y0833 Y0650	Y1228 Y2005
1535 Wharfedale	Y1832	Y0768	Y0790	Y0751	Y1553	Y2065	Y1152	Y0723	Y1115	Y0770